



OP-904 PANEL MOUNT INDICATOR USER'S MANUAL



TABLE OF CONTENTS

| | |
|--|--------------|
| Safety Precautions..... | 1 |
| Features..... | 2 |
| Specifications..... | 3 |
| Display and Key Descriptions..... | 4 |
| Operating Instructions..... | 5 |
| Rear Panel..... | 6 |
| General Functions..... | 7 |
| Function Settings..... | 8 |
| Parameter Settings..... | 9-10 |
| Calibration Settings..... | 11-14 |
| Check Weighing Configuration..... | 15 |
| Cable Connection Manual..... | 16-18 |
| Troubleshooting..... | 19 |
| Contact Us..... | 19 |

SAFETY PRECAUTIONS

For safe operation of the weighing indicator, please follow these instructions:

- Calibration inspection and maintenance of the indicator are prohibited by non-professional staff
- The indicator is a piece of static sensitive equipment; Please cut off power during electrical connections
- Touching the internal components by hand is prohibited
- DO NOT exceed the rated load limit of the unit
- DO NOT step on the unit
- DO NOT jump on the scale
- DO NOT use this product if any of the components are cracked
- DO NOT use for purposes other than weight taking
- To avoid damaging the battery do not keep charger plugged in once battery is fully charged
- Make sure the weight is not over the Max capacity as it could damage the load cell inside
- Material that has a static electric charge could influence the weighing. Discharge the static electricity of the samples, if possible. Another solution to the problem is to wipe both sides of the pan and the top of the case with an anti-static agent
- Plug into a wall outlet to avoid interference with other wirings
- Calibration may be required before weighing when the scale is initially installed or moved from a location

FEATURES

- LED 6 digit display
- Multiple weighing units: kg/lb/t
- Gross/Tare/Hold/Zero
- Check weighing feature

Technical Parameters

Hardware construction features


- Power supply: 24vDC
- Load cell excitation voltage: 5vDC \pm 5%
- Load cell number: up to eight 350 Ω
- Load cell sensitivity: 0~3.0mv/v
- Load cell connections: six wire
- Keyboard: six key
- Display: six digits red 7 segment LED display
- Relay output: 4 output, AC250v 5A
- Input: isolation voltage 2500V
- Analog output: 4~20mA/0~5v
- Serial port: RS232/RS485, baud rate 600~19200bit/s
- Operation temperature: -10 °C ~ +40 °C
- Operation humidity: \leq 90%RH
- Storage temperature: -40 °C ~ +70 °C (32-104°F)
- Housing dimension: 92 x 45mm
- Front panel dimension: 102 x 55mm
- Trepanning dimension: 93 x 46mm

Software features

- Max sampling speed: 120SPS
- AD digital filter
- Digital calibration
- Batching or dosing functions




SPECIFICATIONS

FIGURE 1: INDICATOR MEASUREMENTS



DISPLAY AND KEY DESCRIPTION



| | |
|---|---|
| I/⏻ | Powers the Indicator On or Off if held for 2 seconds |
| ZERO | Zero's the scale |
| TARE | 1. Resets the scale to zero when there is something on the scale (ex. Tare out the weight of a pallet to weigh only the product on it) 2. Clears the tare to see the gross weight (pallet + product) |
| M1 | Displays Gross/Net weight |
| MODE | Setpoint parameter set |
| ENTER | Enter key |
| Zero | Indicates that you have zero'd the scale |
| Motion | The weight on the scale is unstable |
| Gross | Shows you are in Gross weight mode (includes tare); default mode |
| Net | Shows you are in Net weight mode (weight without tared weight) |
| kg | The weight is shown in kilograms |
| t | The weight is shown in tons |
| lb | The weight is shown in pounds |
| Power | Flashes red = low battery, Solid red = charging, Green = fully charged |
| Over | Flashes when weight is higher than set alarm parameter |
| Accept | Flashes when weight is within the set alarm parameters |
| Under | Flashes when weight is lower than set alarm parameter |
|  | Save and Exit |
|  | Arrow keys |
|  | Return/Enter |

OPERATING INSTRUCTIONS

Power On

- Turn on the power by pressing the power button for 2 seconds. Once on, the scale will flash the voltage and then begin to auto-check and count down from 0-9 sequentially before entering the weighing mode

Note: Anything on the scale before powering on will automatically be tared out.


Zeroing

- The zero function is used only when the scale is empty and is not at gross zero due to material build up
- Pressing the ZERO key will reset your scale to 0
- Depending on what your manual zero range parameter is set to, you can zero out any number within your set selection, after that you will receive an error and will need to tare out the weight

Tare Function

- The Tare function is used when you only wish to see the current change in weight, not the entire amount of weight that is on the scale
- When the indicator is in gross mode (gross light is shown) pressing the TARE key will Tare the current weight on the scale and enter the net mode (net light shown)
- For example if you are using a container add the container to the scale, press tare and the display will show the gross light and reset back to 0
- Add your product to the scale to weigh without the weight of the container
- To exit Tare mode press the TARE key again to enter gross mode and you will see the total weight of the container and the product

Note: If you remove the container the scale will show the minus weight of the container



REAR PANEL

Connection definition:

Power: POW+ POW- for 24VDC, AC1 AC2 for 220VAC

Load cell: EXC+ SEN+ EXC- SEN- SIG+ SIG

Serial communications: TXD RXD GND for RS232, A B for RS485

Analog output: Vout Iout GND










Relay output: J1 J1 J2 J2 J3 J3 J4 J4

Input: YX1 YX2 YX3 YX4 YXCOM 0v To exit Tare mode press the TARE key again to enter gross mode and you will see the total weight of the container and the product







Note: If you remove the container the scale will show the minus weight of the container

GENERAL FUNCTIONS

Function setup and operation procedure:

| Function | Operation | Display | Remark |
|---|--|---------|--------|
| Enter calibration mode | Turn the calibration switch to "ON" | 01 CSP | 4 |
| Enter function setting | Weight mode, press  and  | 01 FnC | 3.3 |
| Check weighing setpoint parameter setting | Weight mode, press  | 1.FinAL | 5 |
| Enter to test mode | Turn power on, press  and  | 1. dsp | 7.1 |
| Reset all parameters back to default | Turn power on, turn the calibration switch to "ON", press  and  | i.ALL | 7.2 |
| Reset general function parameters back to default | Turn power on, press  and  | 1 FnC | 7.2 |

Parameter Settings, Key meaning

| Key | Meaning |
|---|--------------------------------------|
|  | Save and Exit |
|  | Move the flashing digit to the left |
|  | Move the flashing digit to the right |
|  | Increase the flashing digit |
|  | Decrease the flashing digit |
|  | Confirm |


FUNCTION SETTINGS


Press  and  at the same time to enter the function settings


The screen will display "01 FnC" for function setting


Press  to display "02 232" for serial port interface


Press  to display "03 Sq " for weight comparison procedures

Press  to display "04 AnL" for analog current output

Press  to display "05 In " for external input interface





Press  to enter the next menu level

Press  to save and exit out of this menu and restart



INDICATOR PARAMETER SETTINGS

To enter parameter settings, follow the procedure below:

1. Press ENTER  and MODE  at the same time for 2 seconds to enter the function settings
2. Navigate through the settings as shown in the table below by using the arrow keys and return keys as labeled under each indicator button
3. Press the ENTER  key to enter/edit the parameter setting
Press the  key to save and exit settings at any time

| 01 FnC Function Parameter Code | | | | |
|--------------------------------|--------|-----------------------------|---|---------|
| Function | Item | Parameter | Description | Default |
| Digital Filter 1 | FnC 01 | 00 01 ... 10 | Greater ↓ Less | 03 |
| Digital Filter 2 | FnC 02 | 00 01 02 03 | Greater ↓ Less | 02 |
| Rate for display rewrite | FnC 03 | 01 05 10 20 120 | 1 times/sec 5 times/sec 10 times/sec 20 times/sec 120 times/sec | 10 |

| 02 232 Serial Port Interface | | | | |
|------------------------------|--------|----------------------------------|--|---------|
| Function | Item | Parameter | Description | Default |
| Baud Rate | 232 01 | 00 01 02 03 04 05 | 600bit/s 1200bit/s 2400bit/s 4800bit/s 9600bit/s 19200bit/s | 04 |
| Transmit Mode | 232 02 | 00 01 02 03 04 | close serial port continuous print mode stable send command mode | 01 |
| Data Format | 232 03 | 00 01 02 | format 1 format 2 print format | 00 |
| Transmit Time | 232 04 | 00 01 02 03 | open 1 sec 2 sec 5 sec | 00 |
| Address for Multi-computer | 232 05 | 00 01~99 | Only one Address (bcd) | 00 |

03 Sq Weight Comparison Procedures

| Function | Item | Parameter | Description | Default |
|-------------------|-------|-----------|--|---------|
| Batching Mode | 59 01 | 00 | normal batch less-in weight comparison | 01 |
| | | 01 | | |
| | | 02 | | |
| | | 03 | | |
| | | 04 | | |
| Control Mode | 59 02 | 01 | manual start auto for custom | 01 |
| | | 02 | | |
| | | 03 | | |
| Comparison Format | 59 03 | 01 02 | net gross | 01 |
| Start Delay | 59 04 | 00 | no delay 1 sec delay ... 10 sec delay | 01 |
| | | 01 | | |
| | | ... | | |
| | | 10 | | |
| Stable Time | 59 05 | 00 | no wait 1 sec wait ... 10 sec wait | 03 |
| | | 01 | | |
| | | ... | | |
| | | 10 | | |

04 Analog Current Output

| Function | Item | Parameter | Description | Default |
|--------------------|--------|------------|--|---------|
| Signal output | AnL 01 | 00 | 4~20mA current 0~20mA current 0~5v voltage | 00 |
| | | 01 | | |
| | | 02 | | |
| Data format | AnL 02 | 00 01 | display weight gross weight | 00 |
| Maximum weight | AnL 03 | 010000 | when max analog output weight | 010000 |
| Zero adjust | AnL 04 | 4mA/0mA/0v | Press ▲ or ▼ to adjust output | 4 |
| Linearity adjust | AnL 05 | 20mA/5v | Press ▲ or ▼ to adjust output | 20 |
| Output range limit | AnL 06 | 00 | no limit limit | 00 |
| | | 01 | | |


05 External Input Interface

| Function | Item | Parameter | Description | Default |
|----------|-------|-----------|---------------------|---------|
| INPUT1 | In 01 | 00 | no function zero | 01 |
| INPUT2 | | 01 | | 02 |
| INPUT3 | In 03 | 03 | gross hold | 05 |
| INPUT4 | | 04 | | |

CALIBRATION SETTINGS

To enter calibration settings, follow the procedure below:

1. In weighing mode, make sure calibration switch is set to "ON"
2. The display will show "01 CSP" meaning you entered the calibration parameter code
 - Press **←** to enter the next step level
 - Follow the steps in the parameters to set up your calibration
3. Press **▲** to display "02 CAL" General calibration
 - Follow the steps to calibrate your scale
4. Press **▲** to display "03 CUo" Sensitivity calibration
 - Follow the steps to set filters and manage the sensitivity of your scale
5. When you are done with calibrating, make sure to turn the switch to "OFF"
6. The screen will display "End" , save the data and restart



"01 CSP" Calibration Parameter Code

| 01 CSP Calibration Parameter Code | | | | |
|-----------------------------------|--------|----------------------------|--|---------|
| Function | Item | Parameter | Description | Default |
| Unit | CSP 01 | 01 02 03 | kg lb t | 01 |
| Decimal point | CSP 02 | 00 01 02 03 04 | none 1 decimal point 2 decimal point 3 decimal point 4 decimal point | 00 |
| Division | CSP 03 | 01 02 05 | division size | 02 |
| Max Capacity | CSP 04 | 010000 | Max capacity | 1000 |
| Zero-Setting range | CSP 05 | 00 01 02 | 0 ±1% ±2% | 02 |
| Initial zero-setting range | CSP 06 | 00 01 02 05 10 | 0 ±1% ±2% ±5% ±10% | 10 |
| Automatic zero-setting range | CSP 07 | 00 05 10 20 | 0 0.5d 1d 2d | 05 |
| Automatic zero-setting time | CSP 08 | 00 01 02 03 | 0 1 sec 2 sec 3 sec | 01 |
| Stable time | CSP 09 | 00 01 02 | fast medium slow | 01 |
| Stable range | CSP 10 | 01 02 05 10 | 1d 2d 5d 10d | 02 |
| Automatic zero | CSP 11 | 00 02 05 10 20 | no -2d -5d -10d -20d | 02 |
| Preserved Menu | CSP 12 | | | |


"02 CAL" Calibration

In weighing mode set calibration switch to "ON"

Calibration press ▲

To enter calibration press ←


Zero calibration press ←

Skip zero calibration press 

Display zero code

3 seconds

Weight calibration press ←

Skip weight calibration press 

Use ▲ ▼ ◀ ▶ to set the weight

Once the weight is stable press ←


Sensitivity

3 seconds, calibration done

Set calibration switch to "OFF"

You are finished

Note: Zero calibration, can be no more than 5mv.



"03 CUo" Sensitivity Calibration

In weighing mode set calibration switch to "ON"

Sensitivity Calibration press ▼

To enter calibration press ←

Zero calibration press ←

Skip zero calibration press ↻

Auto gather zero code

Or press ◀ to set zero code

to enter zero calibration ←

Sensitivity calibration press ←

Skip sensitivity calibration press ↻


Use ▲ ▼ ◀ ▶ to set the sensitivity
enter press ←

Sensitivity calibration done

Set calibration switch to "OFF"

You are finished

Sensitivity = $100000 \times \text{load cell full scale output} \times \text{weighing meter capacity} / (N \times \text{Load cell capacity})$



CHECK WEIGHING CONFIGURATION

Weighing mode press ▼ to go enter parameters

| Display | Function |
|-----------|-----------------|
| 1. FinAL | Final value |
| 2. SP1 | SP1 value |
| 3. SP2 | SP2 value |
| 4. SP3 | SP3 value |
| F. FALL | Free fall value |
| 6. oVer | Over value |
| 7. UndEr | Under value |
| 8. Z.bAnd | Zero band |

Warning: set FinAL > SP1 > SP2 > SP3 > F. Fall

set Sq01=1: net weigh

| Signal | Output Condition | Relay Output |
|-----------|--------------------|--------------|
| SP1 | Net ≥ Final-SP1 | J1 |
| SP2 | Net ≥ Final-SP2 | J2 |
| SP3 | Net ≥ Final-SP3 | J3 |
| Free Fall | Net ≥ Final-F.FALL | J4 |

Set Sq01=3:

| Signal | Output Condition | Relay Output |
|--------|------------------|--------------|
| HI | Net ≥ SP1 | J1 |
| OK | SP1 ≥ Net ≥ SP2 | J2 |
| LO | Net < SP2 | J3 |

CABLE CONNECTION MANUAL

Power

| | |
|------|--------|
| POW+ | 24VDC+ |
| POW- | 24VDC- |
| AC1 | 220VAC |
| AC2 | 220VAC |

Load cell

EXC+
SEN+
EXC-
SEN-
SIG+
SIG-

NOTE: use 4-wire load cell need EXC+ and SEN+ short connect, EXC- and SEN- short connect.

Serial Port

TXD RS232 transmission RXD RS232 receive GND RS232 GND A RS485 A B RS485 B

Analog Output

Vout 0~5v voltage, load more than 1k Ω

Iout 4~20mA current, load span 100~500 Ω

GND GND


Relay Output

J1 J1 first group relay output


J2 J2 second group relay output

J3 J3 third group relay output

J4 J4 fourth group relay output



Relay Output Connection diagram




Common connection diagram


Note: Use common connection, put one of J1, J2, J3, J4 short connect.

Input

- YX1 first group input
- YX2 second group input
- YX3 third group input
- YX4 fourth group input
- YXCOM input common
- 0v out connect power GND



Input Diagram



Out connect power input diagram

Note: Using out electric power needs more than 3V battery charge, Out electric power less than 24V.

TROUBLESHOOTING

Error Codes

| Error | Reason | Solution |
|----------|---|--|
| UUUUUUU | <ol style="list-style-type: none"> 1. Overload 2. Wrong connection with load cell 3. Load cell has quality problem | <ol style="list-style-type: none"> 1. Reduce the weight 2. Check load cell connection 3. Inspect load cell; Check the input/output 4. See Q&A section |
| nnnnnnnn | <ol style="list-style-type: none"> 1. Calibration is no good 2. Wrong connection with load cell 3. Load cell has quality problem | <ol style="list-style-type: none"> 1. Make sure scale is level 2. Check load cell connection 3. Check load cell input and output resistance 4. See Q&A section |
| Err 1 | During calibration, weight is not used or the weight is above the max. capacity | Use correct weight within the defined range |
| Err2 | During calibration, the weight is below the minimum required weight | The calibration weight minimum is 10% of the max. capacity set in C04. Recommended to use 60%-80% of max. capacity if possible |
| Err3 | During calibration, the input signal is negative | <ol style="list-style-type: none"> 1. Check all wire connections 2. Check load cell 3. Recalibrate 4. PCB replacement needed if steps 1-3 fail |
| Err4 | During calibration signal is unstable | After the platform is stable, start calibration |
| Err5 | EEPROM Error | Change PCB |
| Err6 | Exceed Zero Range | See Q&A section |

CONTACT US

Please e-mail sales@optimascale.com for any sales related questions.

Please e-mail support@optimascale.com for any support related questions.

Don't forget to visit our website at:

optimascale.com

