

## OP-722 STRETCH WRAP WEIGHING KIT

### KIT INCLUDES


- 4, 6, or 8 NTEP Alloy Steel Load cells
- Indicator with or without outer casing
- Junction box with summing card
- Leveling feet
- Installation hardware
- Remote Large Display (optional)
- Software (optional)



Shear Beam Load Cells, NTEP certified  
Capacity: 500 lb, 1000 lb, 2500 lb, 5000 lb, 10000 lb



Easy to use OP-900 indicator  
with 0.9" LED display



Example of how assembly can be applied.

### FEATURES

- This weighing kit consists of everything you need to integrate a scale into your stretch wrap machine
- Eliminate wasted time from placing your load on a scale
- Eliminate space used on a separate floor scale
- 200% overload protection on load cells

